



## Part# 542

## Heavy Duty Floor Stop

No exposed fasteners. For use in high vandalism or security areas. For Mounting, drill  $1" \times 2-1/2"$  deep hole - fill with anchoring grout

Size	2" Diameter Base x 1-1/2" High
Material	Black Rubber Bumper

Standard Fasteners 5/8 × 2-1/2" mounting bolt

Copyright ©2025 Burns Manufacturing Inc. All rights reserved. Reproduction in whole or in part without the express written permission of Burns Manufacturing Inc. is prohibited. 2001 Lowell Avenue, Erie, PA 16506 Phone: 800.519.2610 • Fax: 800.432.8767 Website: www.burnsmfg.com Email: burnsmfg@burnsmfg.com